

European Network on New Sensing Technologies for Air Pollution Control and Environmental Sustainability - *EuNetAir*

COST Action TD1105

WGs & MC Meeting at SOFIA (BG), 16-18 December 2015

New Sensing Technologies for Indoor Air Quality Monitoring: Trends and Challenges

Action Start date: 01/07/2012 - Action End date: 30/04/2016 - Year 4: 1 July 2015 - 30 April 2016

Novel Integrated Gas Sensor Microsystem with Pre-Concentrator for Extremely High Sensitivity and Selectivity



UNIVERSITÄT
DES
SAARLANDES



Andreas Schütze

MC member, WG2 leader

Lab for Measurement Technology,
Saarland University, Germany

schuetze@LMT.uni-saarland.de

 **cost**
EUROPEAN COOPERATION IN SCIENCE AND TECHNOLOGY





- VOCs (Volatile Organic Compounds) – a challenge for IAQ
- The SENSIndoor project
- MOFs (Metal-Organic Frameworks) for pre-concentration
- Validation experiments
- Novel integrated microsystem with pre-concentrator
- Simulations
- First experimental results
- Summary and outlook



- Volatile Organic Compounds (VOCs) are highly relevant for IAQ
- Some are proven or suspected to be carcinogenic
- Resulting target concentrations are low ppb or even sub-ppb
→ **High sensitivity required**
- Benign VOCs (e.g. ethanol) can occur at much higher conc. (ppm)
→ **High selectivity required**
- Most relevant target VOCs according to European studies: formaldehyde, benzene, naphthalene

Target gas	Guideline values	
	$\mu\text{g}/\text{m}^3$	ppb
Formaldehyde [1]	100	81.3
Benzene [2]	5	1.57
Naphthalene [1]	10	1.9

[1]: WHO guidelines for indoor air quality (2010)
[2]: Umweltbundesamt Infoblatt Benzol (12/2010)
Note: some national regulations target even lower concentration limits, e.g. France




Motivation

- People spend more than 80 % of their time indoors where fresh air exchange is increasingly limited to reduce energy consumption.
- Indoor air pollution contributes significantly to the global burden of disease.
- Continuous ventilation would greatly increase energy consumption for HVAC (heating, ventilation, air conditioning) systems.
- Low-cost sensor systems are required to provide ubiquitous Indoor Air Quality (IAQ) monitoring.

➤ **Core motivation for the SENSIndoor project**

➤ **Core motivation for the SENSIndoor project**

2 Mio healthy life years are lost every year in the EU due to indoor exposure according to an analysis in the EU project EnVIE




<http://www.efanet.org/wp-content/uploads/2013/02/FINAL-Presentation-all.pdf>

- Demand controlled ventilation today
 - mostly CO₂ monitoring, at best total VOC (TVOC)
 - CO₂ based on IR absorption or solid state electrolyte
 - TVOC based on metal oxide semiconductor (MOS) sensors



E4000 Air Quality Probe
(NanoSense SARL)






SENSIndoor overview

EU Project
SENSIndoor:



Nanotechnology-based intelligent multi-**SEN**sor **S**ystem with selective pre-concentration for **I**ndoor air quality control

www.sensindoor.eu





- **VOC-IDS** (MNT-ERA.net collaborative project)
Volatile Organic Compound Indoor Discrimination Sensor
 - Partners: USAAR-LMT, IDMEC-FEUP - Instituto de Engenharia Mecânica, University Porto (P), UST Umweltsensortechnik GmbH (D), 3S GmbH (D), NanoSense SARL (F), Weinzierl Engineering GmbH (D), CIAT - Compagnie Industrielle d'Application thermique S.A. (F), ALDES Aéraulique S.A. (F)
- COST action TD1105 **EuNetAir**
European Network on New Sensing Technologies for Air-Pollution Control and Environmental Sustainability
 - Partners: U Linköping (A Lloyd Spetz: vice chair of action), U Oulu, USAAR, 3S GmbH, SenSiC AB, SGX Sensortech S.A.
 - Several topics identified to be addressed in call **NMP.2013.1.2-1 Nanotechnology-based sensors for environmental monitoring**

- Sensor technologies
 - **MOS – Metal oxide semiconductor** (*SGX Sensortech, USAAR-LMT*)
 - well known for high sensitivity and robustness @ low-cost
 - MEMS technology for mass production and low power consumption
 - **GasFET – Gas-sensitive Field Effect Transistors** (*LiU, SenSiC*)
 - complementary technology (polarity \leftrightarrow reaction)
 - SiC technology for chemical robustness and high operating temperatures





- Dynamic operation and intelligent signal processing
 - **Temperature Cycled Operation** (*USAAR-LMT, NanoSense, 3S*) to increase selectivity (“virtual multisensor”) and stability



- Nanotechnology for improved sensor elements



- Pulsed Laser Deposition**
(*U Oulu, Picodeon*)

for novel, highly sensitive gas-sensitive layers suitable for wafer level mass production




- Selective pre-concentration** (*FhG-ICT*)

based on MOFs (metal-organic frameworks) → and MIPs ↓ (molecular imprinted polymers)




MOF candidates as PC material



MIL-53


Aluminum 1,4-benzenedicarboxylate



HKUST-1

Copper benzene-1,3,5-tricarboxylate

Surface area > 1000 m²/g



Signal A = SE2 EHT = 2.00 kV Date = 29 Sep 2014 Aperture Size = 20.00 μm
Mag = 10.00 KX WD = 6.7 mm Chamber = 2.36e-04 Pa File Name = DS_11.tif

Are selected MOF materials suitable for PC devices?




Here: tests with benzene

Verification with


- mass spectrometer (MS)
- commercial MOS sensor (UST5330)

μ PCs (2)



MOS sensor


Verification of PC functionality



High benzene concentration: 30 ppm (according to mass spectrometer)

→ Clear signal peaks after heating of MOF coated pre-concentrators

→ Relative peak heights of MS and gas sensor different for both MOFs (water?)



Tests with lower concentrations, here: 1 ppm

→ Influence of accumulation period on signal height during desorption



> μ PC: first proof of concept





Micro pre-concentrator (μ PC):

first proof-of-concept measurements (end 2014) with test gas naphthalene

- μ PC unheated: signal low, then increases
- μ PC @ high temp: signal high, then decreases
- thermal crosstalk



Integrated gas sensor microsystem



SMD ceramic package
(5x7 mm² footprint)

Lid with gas access
not shown

Left:
 μ PC chip

MOF material
 $\varnothing \approx 300 \mu\text{m}$


Right:
Dual gas sensor chip
(SGX Sensortech)

1x WO₃ undoped
1x WO₃ doped


Simulations (Comsol multiphysics)




K1(1)=1e-6 Time=600
Surface: Concentration (mol/m³)




K1(1)=1e-6 Time=600.025
Surface: Concentration (mol/m³)



K1(1)=1e-6 Time=600.5
Surface: Concentration (mol/m³)



K1(1)=1e-6 Time=602
Surface: Concentration (mol/m³)



Background gas concentration:
 $4 \cdot 10^{-7} \text{ mol/m}^3$
(approx. 10 ppb)


Accumulation period:
600 s

Desorption period:
10 s


Simulations show approx. 2 orders of magnitude higher concentration

Note:
colors show relative scales in each image

Point Graph: Concentration (mol/m³)
Point Graph: Concentration (mol/m³)




Point Graph: Concentration (mol/m³)
Point Graph: Concentration (mol/m³)




- Simulation parameters: accumulation period: 600 s, desorption period: 10 s
- Parameter variation: distribution coefficient MOF vs. air (10^{-6} , 10^{-5} , 10^{-4})
- Gas concentrations at both sensor sites – slight delay for second sensor
- Boost in gas concentration (peak): 32x / 20x / 11x
- Higher boost factor corresponds to shorter peaks (typ. few seconds)

First experiments: test protocol






- 300 s accumulation, both sensors and PC off to prevent thermal crosstalk
- @ 298 s: sensors heated to 400°C for 2 s → surface “cleaning”
- @ 300 s: pre-concentrator device heated to 200°C for 180 s → desorption

First results for benzene



- Peak @ 298 – 300 s caused by high temperature (not evaluated)
- Sensor response at $t > 300$ s caused by temperature (sensor/housing) **and gas**
- Several points selected and plotted as quasi-static sensor signals

First results for benzene




G/G_0 (cycle with gas / cycle in air)

Signal @ 10 ppb during pre-concentrator desorption nearly as high as for 100 ppb without pre-concentrator

→ **boost in sensitivity**

First results for benzene



Maximum sensitivity in cycle changes with concentration → additional information



- Novel integrated low-cost microsystem with pre-concentration
- Boost in sensitivity was demonstrated, but lower than expected
- Problems of first integrated prototypes:
 - μ PC heater area was not used efficiently (optimum: 8* larger)
 - Poor adhesion of MOF materials on micro hotplate
 - Interfering signal in mounted systems (caused by glue?)
- Outlook
 - New MOF deposition methods to be tested (screen printing?)
 - Improved adhesion
 - Optimized dynamic **system** operation (PC T ramp, sensor T cycle,...)
 - Boost in selectivity needs to be verified



SENSIndoor consortium
2nd progress meeting, Pfinztal, Jan. 2015



The SENSIndoor project has received funding from the European Union's Seventh Framework Programme for research, technological development and demonstration under grant agreement No 604311.

